

FRONT
11 x 16 cm.

BACK
11 x 16 cm.

M09370 SERIES




Installation Instructions

1. Drill hole in the panel, 1-1/8" dia.
2. From the front of the panel, insert the wire and control box into the mounting hole.
3. Slide the rubber grommet down off the lamp so that the grommet is now on the wire.
4. From the front of the panel, insert the grommet into the mounting hole and press down until it is properly seated.
5. Insert the lamp into the grommet and press down until the lamp is properly seated.

Note:The chrome bezel cannot be removed. If it is desired to remove the bezel, it must be cut off.
M09370 series can also be synchronized or alternate flash with M20372 series.
The wiring instructions are the same for both lamp series."

WIRING INSTRUCTIONS

Simultaneous Flash



Step 1 Power Connections


- a) Connect all black wires to Ground
- b) Connect all red wires to +12 VDC
- c) Connect all yellow wires together
- d) White wires are not used for "Simultaneous flash"

Step 2 Set Flash Pattern

- a) Connect all yellow wires to +12 VDC (red Wire) hold for 7 seconds. This is Pattern 0, the default setting. Remove connection.
- b) Connect yellow wire to + 12 VDC (red wire) momentarily (less than one second) to change to the next flash pattern. Repeat this operation until the desired flash pattern is reached.

All lamps will flash simultaneously.

Alternate Flash




Make connections as in Step 1

Connect all white wires of Group 1 to +12 VDC (red wire). Group 2 white wires are not connected and may be removed. (Any group can be designated "Group 1")

Set flash pattern per Step 2

Group 1 will flash the set flash pattern alternately with Group 2

Single Lamp



FLASH SEQUENCE

0 Random (default)	4 Double	8 8 Flash
1 Steady	5 Triple	9 Single-Quad
2 Single	6 Quad	10 Single H/L
3 Mega	7 Quint	11 Single-Triple-Quint

To select Flash Pattern, apply +VDC to YELLOW wire:
 • for less than 1 second for next pattern
 • press and hold for 7 seconds to reset

Make connections as in Steps 1 & 2. The white wire is not used for a single lamp installation.